

Temperature Meter

K3NH

High-performance Temperature Meter Accepts Temperature/Analog Inputs

- Multirange capability: a single processor connects to 14 types of sensors with varying current/voltage
- Programmable through the front panel or via RS-232C, RS-485, or RS-422
- Programming with easy setup and calibration
- Output boards include communications and linear boards
- High accuracy: 100-ms sampling for analog input
- High visibility: 14.2-mm red LED display
- °C/°F display selection
- NEMA4/IP66 front panel
- UL, CSA, and CE approved





91 \$ (E

Ordering Information _____

■ BASE UNIT

Model	Supply voltage	Applicable output boards	Part number
Basic model	100 to 240 VAC	K31-C1/C2/C5 K31-T1/T2 K31-B2/B4 K31-L1/L2/L3/L4/L5/L6/L7/L8/L9/L10 K31-FLK1/FLK2/FLK3/FLK4/FLK5/FLK6	K3NH-TA1A
	12 to 24 VDC		K3NH-TA2D
Present value LED and front-panel control keys. Can connect to any output board or, without an output board, can be used for display only.			
Set value LED model	100 to 240 VAC	K31-C1/C2/C5 K31-T1/T2 K31-B4 K31-L4/L5/L6/L9/L10 K31-FLK4/FLK5/FLK6	K3NH-TA1C
	12 to 24 VDC	, .	K3NH-TA2C
Present value LED, set value LED, and front-panel control keys. Can connect to relay, transistor, or combination output boards.			

Note: "Set Value LED" models must be used with an output board in order for them to operate.

■ RANGES

Platinum Resistance Thermometer

Input		JPt100	Pt100
Range	°C	-199.9 to 650.0	–199.9 to 650.0
	°F	-199.9 to 999.9	–199.9 to 999.9
Parameter		JPE	PĿ

Thermocouple

Input (See Note.))	K1	K2	J1	J2	Т	Е	L1	L2	C	Ν	R	S	В	W	РШ
Range	°C	-200 to 1,300	0.0 to 500.0	-100 to 850	0.0 to 400.0	-199.9 to 400.0	0 to 600	-100 to 850	0.0 to 400.0	-199.9 to 400.0	-200 to 1,300	0 to 1,700	0 to 1,700	100 to 1,800	0 to 2,300	0 to 1,300
	°F	-300 to 2,300	0.0 to 900.0	-100 to 1,500	0.0 to 750.0	-199.9 to 700.0	0 to 1,100	-100 to 1,500	0.0 to 750.0	-199.9 to 700.0	-300 to 2,300	0 to 3,000	0 to 3,000	300 to 3,200	0 to 4,100	0 to 2,300
Parameter		PICR	Y2 CR	3120	32 20	F CC	E Er	LIJE	15 <u>2</u> E	и сс	п	r Pr	5 Pr	ь Рг	<u> 4</u> 526	PL 2

Note: Thermocouple W is W/Re5-26 (Tungsten rhenium 5, tungsten rhenium 26).

Current/Voltage

Input	Current input		Voltage input		
	4 to 20 mA	0 to 20 mA	1 to 5 V	0 to 5 V	0 to 10 V
Range	One of following ranges depending on res -1999 to 9999 -199.9 to 999.9 -19.99 to 99.99 -1.999 to 9.999				
Parameter	4-20	0-20	1-5	0-5	0- 10

■ AVAILABLE OUTPUT BOARD COMBINATIONS

Output type	Output configuration	Part number
Relay contact	3 outputs: H, PASS, L (SPDT)	K31-C1
	5 outputs: HH, H, L, LL (SPST-NO), and PASS (SPDT)	K31-C2
	5 outputs: HH, H, L, LL (SPST-NC), and PASS (SPDT)	K31-C5
Transistor	5 outputs (NPN open collector)	K31-T1
	5 outputs (PNP open collector)	K31-T2
BCD (See Note.)	5-digit output (NPN open collector)	K31-B2
Linear	4 to 20 mA DC	K31-L1
	1 to 5 VDC	K31-L2
	1 mV/10 digits	K31-L3
	0 to 5 VDC	K31-L7
	0 to 10 VDC	K31-L8
Communication boards	RS-232C	K31-FLK1
(See Note.)	RS-485	K31-FLK2
	RS-422	K31-FLK3
Combination output and	BCD output + 5 transistor outputs (NPN open collector)	K31-B4
communication boards	4 to 20 mA + 5 transistor outputs (NPN open collector)	K31-L4
	1 to 5 V + 5 transistor outputs (NPN open collector)	K31-L5
	1 mV/10 digits + 5 transistor outputs (NPN open collector)	K31-L6
	0 to 5 VDC + 5 transistor outputs (NPN open collector)	K31-L9
	0 to 10 VDC + 5 transistor outputs (NPN open collector)	K31-L10
	RS-232C + 5 transistor outputs (NPN open collector)	K31-FLK4
	RS-485 + 5 transistor outputs (NPN open collector)	K31-FLK5
	RS-422 + 5 transistor outputs (NPN open collector)	K31-FLK6

Note: For details, refer to the Communication Operation Manual (N96).

K3NH	OMRON	K3NH
101111	<u> </u>	1201111

■ MODEL NUMBER LEGEND

Base units and output boards are available individually. Refer to the Available Output Board Combinations table provided within Ordering Information.

Base Units

K3NH -

1, 2. Input Sensors Codes 3. Supply Voltage

TA: Current series

4. Display

1: 100 to 240 VAC A: Basic Model
2: 12 to 24 VDC C: Set Value LED Display

Specifications _____

■ RATINGS

Supply voltage		100 to 240 VAC (50/60 Hz); 12 to 2	1 VDC		
11 7 0					
Operating voltage ra		85% to 110% of supply voltage			
Power consumption	(See Note.)	15 VA max. (max. AC load with all i 10 W max. (max. DC load with all ir			
Insulation resistance	•	20 M Ω min. (at 500 VDC) between insulation provided between inputs,			
Dielectric withstand	voltage	2,000 VAC for 1 min between exter insulation provided between inputs.			
Noise immunity		±1,500 V on power supply terminals noise with 1 ns	s in normal or common mode ±1 μs, 100 ns for square-wave		
Vibration resistance		Malfunction: 10 to 55 Hz, 0.5-mm for 10 min each in X, Y, and Z directions Destruction: 10 to 55 Hz, 0.75-mm for 2 hrs each in X, Y, and Z directions			
Shock resistance		Malfunction: 98 m/s² (10G) for 3 times each in X, Y, and Z directions Destruction: 294 m/s² (30G) for 3 times each in X, Y, and Z directions			
Ambient	Operating	-10 to 55°C (14 to 131°F) with no icing			
temperature	Storage	-20 to 65°C (-4 to 149°F) with no icing			
Ambient humidity	Operating	25% to 85% (with no condensation)			
Ambient atmosphere		Must be free of corrosive gas			
EMC	Emission AC Mains: EN55011 Group 1 class A Immunity ESD: EN61000-4-2: 4-kV contact discharge (level 2) 8-kV air discharge (level 3)		EN55011 Group 1 class A EN61000-4-2: 4-kV contact discharge (level 2) 8-kV air discharge (level 3) ENV50140: 10 V/m (amplitude modulated, 80 MHz to 1 GHz)		
		Immunity Conducted Disturbance: Immunity Burst:	(level 3) 10 V/m (pulse modulated, 900 MHz) e: ENV50141: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-4: 2-kV power-line (level 3) 2-kV I/O signal-line (level 4)		
Approved standards		UL508, CSA22.2, CE; conforms to EN50081-2, EN50082-2, EN61010-1 (IEC1010-1); conforms to VDE106/part 100 (Finger Protection) when the terminal cover is mounted.			
Weight		Approx. 400 g			

Note: An Intelligent Signal Processor with DC supply voltage requires approximately 1 A DC as control power supply current the moment the Intelligent Signal Processor is turned on. Do not forget to take this into consideration when using several Intelligent Signal Processors. When the Intelligent Signal Processor is not in measuring operation (e.g., the Intelligent Signal Processor has been just turned on or is operating for startup compensation time), the display will read "00000" and all outputs will be OFF.

■ INPUT/OUTPUT RATINGS

Relay Contact Output (Incorporating a G6B Relay)

Item	Resistive load (cosφ = 1)	Inductive load (cosφ = 0.4, L/R = 7 ms)	
Rated load	5 A at 250 VAC; 5 A at 30 VDC	1.5 A at 250 VAC, 1.5 A at 30 VDC	
Rated carry current	5 A max. (at COM terminal)		
Max. contact voltage	380 VAC, 125 VDC		
Max. contact current	5 A max. (at COM terminal)		
Max. switching capacity	1,250 VA, 150 W	375 VA, 80 W	
Min. permissible load (P level, reference value)	10 mA at 5 VDC		
Mechanical life	50,000,000 times min. (at a switching frequency of 18,000 times/hr)		
Electrical life (at an ambient temperature of 23°C)	100,000 times min. (at a rated load switching frequency of 1,800 times/hr)		

Transistor Output

Rated load voltage	12 to 24 VDC ^{+10%} / _{-15%}
Max. load current	50 mA
Leakage current	100 μA max.

BCD Output

I/O signal na	ame	Item	Rating
Inputs	REQUEST, HOLD,	Input signal	No-voltage contact input
	MAX, MIN, RESET	Input current with no-voltage input	10 mA
		Signal level	ON voltage: 1.5 V max. OFF voltage: 3 V min.
Outputs	DATA, POLARITY,	Rated load voltage	12 to 24 VDC ^{+10%} / _{-15%}
	OVERFLOW, DATA VALID, RUN	Max. load current	10 mA
	, i	Leakage current	100 μA max.

Note: Logic method: negative logic

Linear Output

Item	4 to 20 mA	1 to 5 V	1 mV/10 digits (See Note.)
Resolution	4,096		
Output error	±0.5% FS		±1.5% FS
Permissible load resistance	600 Ω max.	500 Ω min.	1 KΩ min.

Note: For the 1 mV/10-digit output, the output voltage changes for every 40 to 50 increment in the display value.

■ COMMUNICATIONS

Item		RS-232C, RS-422	RS-485	
Transmission meth	od	4-wire, half-duplex	2-wire, half-duplex	
Synchronization me	ethod	Start-stop synchronization		
Baud rate		1200/2400/4800/9600/19200/38400 bps		
Transmission code ASCII (7-bit)		SCII (7-bit)		
Communications	Write to K3NH	Comparative set value, scaling value, remote/local programming, reset control of maximum/minimum values, and other setting mode items excluding communications conditions		
	Read from K3NH	Process value, comparative set value, maximum value, minimum value, model data, error code, and others		

For details, refer to the Communication Operation Manual (N96).

■ CHARACTERISTICS

Indication accuracy (at 23±5°C)	Thermocouple	(±0.3% of indication value or ±1°C, whichever greater) ±1 digit max.
	Platinum resistance thermometer	(±0.2% of indication value or ±0.8°C, whichever greater) ±1 digit max.
(See Note.)	Analog input	±0.2% FS ±1 digit max.
Input	Thermocouple	K, J, T, E, L, U, N, R, S, B, W, PLII
·	Platinum resistance thermometer	JPt100, Pt100
	Current input	4 to 20 mA, 0 to 20 mA
	Voltage input	1 to 5 V, 0 to 5 V, 0 to 10 V
Sampling period	Temperature input	250 ms
	Analog input	100 ms
Input shift		Two-point settings (upper limit and lower limit)
Max. displayed digits		5 digits (-19999 to 99999)
Display		7-segment LED
Polarity display		"-" is displayed automatically with a negative input signal.
Zero display		Leading zeros are not displayed.
HOLD function		Maximum hold (maximum data) Minimum hold (minimum data)
External controls		HOLD: Process value held RESET: Maximum/Minimum data reset
Comparative output hysteresis setting		Programmable with front-panel key inputs (1 to 9999).
Other functions		Variable linear output range (for models with linear outputs only) Remote/Local processing (available for communications output models only) Maximum/Minimum value data reset with front panel keys °C/°F display selection Averaging processing function (simple or moving average) Comparative output pattern selection Standby sequence Security Field calibration
Output configuration		Relay contact output (5 outputs) Transistor output (NPN and PNP open collector), BCD (NPN open collector) Parallel BCD (NPN open collector) + transistor output (NPN open collector) Linear output (4 to 20 mA, 1 to 5 V) + transistor output (NPN open collector) Communication functions (RS-232C, RS-485, RS-422) Communication functions (RS-232C, RS-485, RS-422) + transistor output (NPN open collector)
Delay in comparative outputs (transistor output)		500 ms max.
Enclosure rating	Front panel	NEMA4 for indoor use (equivalent to IP66)
	Rear case	IEC standard IP20
	Terminals	IEC standard IP00
Memory protection		Non-volatile memory (EEPROM) (possible to rewrite 100,000 times)

Note: The indication accuracy of the K1, T, and N thermocouples at a temperature of -100°C or less is ±2°C ±1 digit maximum. The indication accuracy of the U, L1, and L2 thermocouples at any temperature is ±2°C ±1 digit maximum.

The indication accuracy of the B thermocouple at a temperature of 400°C or less is unrestricted.

The indication accuracy of the R and S thermocouples at a temperature of 200°C or less is ±3°C ±1 digit maximum.


The indication accuracy of the W thermocouple at any temperature is $(\pm 0.3\%)$ of the indicated value or $\pm 3\%$, whichever is greater) ± 1 digit maximum.

The indication accuracy of the PLII thermocouple at any temperature is (±0.3% or ±2°C, whichever is greater) ±1 digit maximum.

MONIL	OMRON	V 2NIL
K3NH		K3NH

Nomenclature

■ K3NH



Name	Functions
1. SV display	Displays the set value or parameter. Available for Set Value LED Models only.
2. PV display	Displays the process value in addition to the max/min value or parameter.
3. Comparative output status indicators	Displays the status of comparative output.
4. SV display status	Indicates which comparative set value is currently on the SV display.
5. ESC Key	Used to return to the RUN mode from the Setting, Protect, or Maintenance mode. The process value, maximum value, or minimum value to be displayed can be selected.
6. Mode Key	Used to enter the Setting mode. Used to allow the PV display to indicate set values sequentially. Available for Basic Models only. Used to indicate set values sequentially on the SV display. Available for Set Value LED Models only.
7. Status indicators	HOLD: Lit when HOLD input is ON. MAX: Lit when the maximum value is indicated on the PV display. MIN: Lit when the minimum value is indicated on the PV display. PROG: Lit or flashes while parameters are being set.
8. Teaching indicator	Lit when the teaching function is enabled and flashes when the Intelligent Signal Processor is in teaching operation.
9. RESET/TEACH Key	The maximum value and minimum value are reset by pressing this key. Teaching is available when the teaching function is enabled.
10. Up Key and Shift Key	The digit being set is scrolled by pressing the Shift Key. The set value increases by one whenever the Up Key is pressed.

Operation

■ SETTING PROCEDURES

The K3NH has four modes: RUN mode for normal operations, Setting mode for initial parameter input, Protect mode for lock-out configuration, and Maintenance mode for initializing set values and user calibration. The parameters that are accessible on any individual K3NH will vary depending on the output board installed. Refer to the K3NH Operation Manual for details.

RUN Mode: Remains in this mode under normal operation.

The process value or the max./min. value can be monitored.

Using the front panel keys, the comparative set value can be changed and max./min. values reset can be performed.


Setting Mode: Used for making initial settings.

Includes settings for three menus (Set value ($5\omega 5EE$), setup (5EEUP), option ($\bar{a}PE$)) and the output test.

Protect Mode: Used for locking the front key operation or parameter changes.

Maintenance Mode: Used for initializing set values and user calibration of the inputs.

The user calibration is valid for selected input ranges.



5u5Et - Program set values

5u.HH Enter set value HH

5u. H Enter set value H

5u. L Enter set value L

5u.LL Enter set value LL

5EEUP - Program input type/Serial communications

En-L Determine input type

E--F Select the °C/°F display

En-H Scaling upper limit

En-L Scaling lower limit

dEE-P Select decimal point

บ-กอ์ Enter the unit no. for the host

6P5 Select the baud rate

LEn Select the word bit length

5626 Select the stop bits

Prt9 Select the parity bits

5Pb - Supplementary settings related to display or control

Set for averaging process value

ช่วนีวัน Select the number of digits to be displayed

En5H Select shift amounts of input shift upper limit values

En5L Select shift amounts of input shift lower limit values

H35 Enter hysteresis value

E-ōUŁ Select the output pattern

5Edb3 Enable standby sequence

LSELH Enter the upper limit (H) of linear output range

LSEELL Enter the lower limit (L) of linear output range

r-L Select the remote/local programming

EESE - Generating simulated input for testing the output function

PrāŁ - Program lock-out configuration

FLL Enable all key protection

505EL Enable set value change prohibition

nac 5 Enable prohibition of max./min. value reset using the

front panel keys


5EEr Specify the menus to be protected against setting in

the setting mode


■ PARAMETERS

Scaling Upper/Lower Limit [n-H/[n-L

When the input type is set to the current/voltage input, input signals can be converted and displayed in the desired display value. The setting can be made by inputting display values that correspond to the upper-limit input value and lower-limit input value for the selected input type. The decimal point can be set to any position.



When displaying the 4- to 20-mA input as 20.0% to 95.0%.




Average Processing Ru5

The average processing function stabilizes displayed values by averaging the corresponding analog input signals that fluctuate dynamically or reducing the noise in the input signals.

Input Shift In5H/In5L

When temperature input is selected, scaling is not required. This is because input is treated as the "temperature" as it is matched to the input type. However, note that the upper- and lower-limit values of the sensor can be shifted. For example, if both the upper- and lower-limit values are shifted by 1.2°C, the process value (before shift) is regarded as 201.2°C after shift when input is 200°C before shift.




Hysteresis #35

The hysteresis of comparative outputs can be set to prevent the chattering of comparative outputs. For more details, refer to *Output Operation Timing in Run Mode* (found later in this section).


Output Pattern Selection [-50]

The patterns of comparative output are selectable according to the level change. Select the pattern according to the application.


Standard Output



Zone Output



Level Output



Note: The following setting conditions must be satisfied, otherwise the zone output will not turn ON correctly.


LL < L < H < HH

Standby Sequence 52865

The comparative output operation can be disabled from when the power supply is turned ON to when it enters the PASS range. This is effective for avoiding any unnecessary output until the output reaches the measurement range after the power is turned ON.


(Since other comparative output operations are disabled until the output falls within the PASS range, comparative output operation may not be performed if the settings are incorrect. Therefore, be careful when selecting the comparative output pattern and setting various comparative values.)

Example: When the standby sequence function is ON.



Linear Output Range LSEL


A linear output range can be set as required. A value corresponding to the maximum output value and that corresponding to the minimum output value can be set.




Remote/Local Selection r - L

Select remote programming when performing all settings through the host devices and select local programming when performing settings through key operation.

■ TERMINAL ARRANGEMENT




Terminal Numbers



Note: Terminals 7 to 13 are connected internally.

■ INPUT UNIT



When inputting the external control signals through the open collector:

Transistor Inputs:

ON: Residual voltage must be 3 V max.


OFF: Leakage current must be 1.5 mA max.

The switching capacity must be 20 mA or greater.


When the external signal input is short-circuited, a voltage of approximately 5 V will be applied between terminals 5 and 7 and the COM terminal, and a current of approximately 18 mA (nominal value) will flow.

■ OUTPUT BOARDS


K31-C1: Relay (3 Outputs)




K31-C2: Relay (5 Outputs)




K31-C5: Relay (5 Outputs)




K31-T1: Transistor (NPN Open Collector)



K31-T2: Transistor (PNP Open Collector)




K31-B2, -B4: BCD (NPN Open Collector)




K31-L1, -L2, -L3, -L4, -L5, -L6, -L7, -L8, -L9, -L10: Linear

(Terminals 21 to 26 are provided only on K31-L4, -L5, -L6, -L9, -L10.)



K31-FLK1: RS-232C

COMMON



K31-FLK2, -FLK5: RS-485

Terminator

(Terminals 21 to 26 are provided only on K31-FLK5.)

RS-485 ON Outputs (50 mA max. at 12 to 24 VDC)
+ - OFF HH H PASS L LL COM

18 19 20 21 22 23 24 25 28

• D-sub 37P connectors for BCD output (order separately)

Plug: XM2A-3701 Hood: XM2S-3711

• D-sub 25P connectors for RS-232C output (K31-FLK1)

(order separately) Plug: XM2A-2501 Hood: XM2S-2511

• D-sub 9P connectors for RS-422 output (K31-FLK3 and

K31-FLK6) (order separately)


Plug: XM2A-0901 Hood: XM2S-0911

• D-sub 9P connectors for RS-232C output (K31-FLK4)

(order separately) Plug: XM2D-0901 Hood: XM2D-0911

K31-FLK3, -FLK6: RS-422

(The right-hand side connector is provided only on K31-FLK6.)



K31-FLK4: RS-232C + Transistor (NPN Open

Collector)


Output NPN Tr.
(50 mA max. at 12 to 24 VDC)





■ OUTPUT OPERATION TIMING IN RUN MODE (RELAY OR TRANSISTOR OUTPUTS)

The following timing chart is for a 5-comparative output board when the standard output pattern is selected




Note: The hysteresis value set in setting mode will be applied to all set values.

■ BCD OUTPUT TIMING CHART

A request signal from an external device (such as a Programmable Controller) is required to read BCD data.


Single Sampling Data Output




Approximately 30 ms after the REQ signal rises, a sample is taken and the DATA VALID signal is output. Read the data when the DATA VALID signal is ON.

The DATA VALID signal will turn OFF in 40 ms, and then in 16 ms, the data will go OFF.


Models with a BCD output have an open collector output configuration so that wired-OR connection is possible.





*The period between the DATA VALID signal and the REQ signal should be no less than 20 ms max.


Continuous Data Output



The K3NH outputs each measurement at an interval of 64 ms when a REQ signal is ON continuously.


If the HOLD signal is ON at the moment the DATA output is switched from data 1 to data 2 or vice versa, the output BCD data will be either data 1 or data 2 according to the timing of the HOLD signal. However, output data will never be low.

■ BLOCK DIAGRAM




Application Examples


■ INSPECTION LINES FOR GAS APPLIANCES




■ INTERFACING LARGE EXTERNAL DISPLAYS




■ MONITORING EXHAUST TEMPERATURES ON MARINE ENGINES




■ TEMPERATURE MONITORING FOR PLATING AND COATING BATHS




■ CENTRALIZED TEMPERATURE MONITORING FOR INDUSTRIAL FURNACES




■ TEMPERATURE DISPLAY AND ALARMS FOR FORMING EQUIPMENT



■ MONITORING BEARING TEMPERATURE ON GENERATORS AND MOTORS



■ TEMPERATURE MONITORING AND CONTROL INTERFACES FOR MULTILEVEL ALARMS





Dimensions


Unit: mm (inch)

■ K3NH










Installation

■ EXAMPLE OF CONNECTION TO PROGRAMMABLE CONTROLLER



Precautions

■ AVOID ELECTRIC SHOCK


- · Do not touch any terminals.
- Do not disassemble the product or touch the internal components of the product.
- Be sure that the power supply voltage is within the rated range.
- Do not use the Intelligent Signal Processor in locations with flammable gas or combustible substances.
- Be sure to wire the terminals correctly by checking the terminal names.
- Be sure that the terminal screws are tightened securely when wiring.

OPERATION

- A Processor model with a relay contact or transistor output board may not output any alarm signal normally if the model has an error. It is recommended that an independent alarm device be connected to the model.
- The parameters are factory-set for normal operation. The settings of the parameters may be changed according to the application.

MOUNTING


Recommended panel thickness is 1 to 3.2 mm.



- Attach the mounting bracket on the left and right sides of the Intelligent Signal Processor (as shown in the illustration above). Gradually tighten each screw evenly, balancing the tightening force until the ratchet starts to slip.
- Mount the Processor as horizontally as possible.
- Never use the Processor in locations where corrosive gas (particularly sulfur or ammonia gas) is generated.
- Avoid use of the Processor in a location subject to severe shock or vibration, excessive dust, or excessive moisture.
- Select an indoor mounting location where the Intelligent Signal Processor is at the rated temperature and humidity and free from direct sunlight.
- Separate the Processor from machines generating high-frequency noise, such as high-frequency welding machines and high-frequency sewing machines.

■ UNIT LABEL (ATTACHED)

No product is shipped with the unit label attached. Select a unit label from the sheet provided and attach it to the Processor.





OMRON CANADA, INC. 885 Milner Avenue Scarborough, Ontario M1B 5V8 416-286-6465